

for the Steffes Transceiv with Steffes Connect.







## **TABLE OF CONTENTS**

Log-In to Steffes Connect	1
Dashboard	2-3
Devices Tab	4-8
Device Detail	4
Setback	5
Device Sharing	6
Edit Device	
Device Notifications	7
Weather Forecasting	8
Locations Tab	8-9
5 – Day Weather Forecast	8
Location Detail	
Register Location	
Account Profile	
Notification Settings	
Icon for Smart Phone	



Click on the Steffes Connect icon on the top left of the screen at any time to return to your dashboard page.




Click one of these icons in the top right corner of a screen to open a drop-down menu for navigation of Steffes Connect.

- Click on the pencil to edit a screen. If the pencil is not available that screen is not able to be edited.
- Shows device is online.
- Shows device is offline.
- Click on the plus sign to add/share a device or to add information.
- Click on the question mark to see additional information.

# Steffes Connect Webpage: Log-In/Account Creation

- Webpage location:
  - <a href="https://steffesconnect.com">https://steffesconnect.com</a>
- New accounts require a valid email address for verification during account creation process.
- Device linking requires MAC Address/ Verification Code





Label on the postcard included with the transceiver.

MAC Address: F8:F0:05:XX:XX:XX Verification Code: XXXX Access Point Setup link: setup.steffes.com

# Steffes Connect Webpage: Dashboard


Computer Dashboard Example






Smartphone Dashboard Example


#### **Dashboard**



### **Devices Tab**



#### **Device Detail**



Click the pencil on the top left of the screen to Edit.

Click here to

return to the

Devices tab

Click on any tab

to see specific

device details.

#### What is Setback:

Room temperature setback is a simple strategy to help save cost by reducing how often your heating system operates. This is achieved by allowing the temperature in the home to adjust to a lower temperature.


Room temperature setback works well in applications where the area being setback will not be used on a regular basis such as a weekend home, cabin, church, school, etc.

It is not advisable to do room temperature setback unless the duration of the setback is 10-hours or more. Using room temperature setback will alter how the heater stores heat. Since energy usage will be reduced during the away (setback) time, the ETS heater will think it needs to store a smaller amount of heat.

If utilizing setback with ETS equipment, it is strongly advised to have the home (set forward) initiated early enough in the offpeak period so the home can be up to temperature prior to going into the on-peak (control) period.


Configuration 12 on the heater display MUST be changed to the room temperature the heater is to maintain during the away (setback) time. Factory default is 60°F/15.6°C.

#### **Device Detail**




NOTE: Setback is applicable to 2000 and 2100 Series heaters only. Setback times will reflect the Power Providers time zone.

#### **Setback Example**




NOTE: Must set two scheduled times when crossing midnight.




changes.

#### Page 5

# Additional Device Details



#### **Device Detail**



#### Forecasting:


Allows the average temperature for the upcoming 24 hours to be used as the outdoor temperature. This temperature is based on the zip code used for the transceiver location. This feature allows the heater to be prepared for future heat calls.

If the transceiver goes offline the heater will default to the outdoor temperature as sensed at the transceiver.

0 STEFFES = **EDIT DEVICE** Location TV Device Type Transceiver Model 2-POLE Notification Settings → Temperature Adjustment Indoor Temperature Offset in °F Use Weather Forecast for Outdoor Temperature Cancel Delete Device

To delete a device from your Steffes Connect webpage click here then confirm.

### **Location Tab**




# 5-Day Weather Forecast



Page 8

#### **Location Detail**



Click to

access

Device


Details.

NOTE: Only locations with no linked device can be deleted. To delete a location click on desired location, click on the pencil in the top right corner for edit, scroll to the bottom of the page and click on Delete Location.

Click to add an additional device to your Steffes Connect account.

Location Details.


#### **Register Location**




Input information to register a new location.

Select a power provider rate schedule in your area from the drop-down menu.

Click Submit to save changes.



#### **Dashboard**






Click on down arrow or 3 lines in top right of screen to access the dropdown menu at any time for:

Account Settings
Notification Settings
Contact Us
Logout

#### **Account Profile**



Click to edit
Account
Profile.

Click on the Steffes Connect logo at any time to return to the dashboard.

Change phone number for SMS (text message) notifications.

Change first and last name. —

Click Save to save changes.


#### **Edit Account Profile**

OFILE
OFF O
°F °C
ice   End User License

Two-factor authentication on/off.
Enable the two-factor authentication
to require a SMS (text message)
code before every login.

Change Fahrenheit or Celsius.


#### **Account Profile**



NOTE: When changing the device password remember password must be a minimum of 6 characters, include one (1) each uppercase and lowercase letter, One (1) number, and one (1) special character.


Click to change the device password.

#### **Change Password**



Always click Change Password to save changes.


A green shaded notice will show up at the top of any page once edits have been made and saved.



NOTE: Any active notifications set here will default to all registered devices. To change notifications to an individual device, follow instructions on page 6.




#### **Notification Settings**



Click the pencil in the top right corner of the screen to Edit Notification Settings. Notifications can be received by email, text message, or both. Notifications will be received if temperature is above or below set temperature and/or device is offline.

#### **Edit Notification Settings**



to save changes.

Always click Save

Set up notifications you would like to receive. Click the box for

a green check mark to mark

the notifications you would like

to receive as active.

Icon for Smart Phone
NOTE: Optional Only. Device models may differ from images shown. Contact your phone service provider for additional assistance.

Step 1: Open Steffes Connect in the web browser. Tap share icon for pop up menu.

Α

P


E

Α

R




Step 2: Scroll to Add to Home Page. Tap for next pop up screen.




Step 3: Tap Add to add icon to device home screen.




Step 1: Open Steffes Connect in your web browser. Tap the 3 dots or 3 lines for pop up menu.




Step 2: Tap on Home Screen to add to the device home screen.



Step 3: Additional pop up screens may come up. If so, follow prompts to add icon to the device home screen.





Page 13

Thank you for purchasing Steffes ETS heating equipment. We welcome your comments relating to this manual. Enjoy your new purchase!



3050 Highway 22 North Dickinson ND 58601-9413 © 2020 Steffes ETS, LLC All Rights Reserved PRINTED IN USA