


2000 CFM
Air Handler



3000 CFM
Air Handler




Diagram Number	Item Order Number	Diagram Item Description
1	1012026	190° Manual Reset Limit Switch
2	1041536	Discharge Air Sensor
3	1012008	160° Reset Limit Switch
4	1041842	Limit Mount Assembly- includes Harness
5	1018006	Capacitor 10 MFD
5	1018001	Strap
5	1018002	Boot
6	1013052	Damper Motor
7	1012008	190° Auto
8	1018007	Capacitor 8 MFD
8	1018000	Strap
8	1018002	Boot
9	1041860R	Replacement/Upgrade 8100 Core Blower Assembly
10	1041852	2000 CFM Supply Blower Assembly
10	1020015	Motor ¾ hp
10	1021004	Housing/Wheel
10	1018023	Bracket-Motor Mounting
11	1041856	Lower 3000 CFM Supply Blower Assembly
11	1020006	Motor
11	1021000	Housing with Wheel
12	1041856	Upper 3000 CFM Supply Blower Assembly
12	1020006	Motor
12	1021000	Housing with Wheel